



Operating manual for Incognito, Tribune, Maestro automatic watches


Crown (A) pushed down
Position 1



Crown (A) pulled one “click” out
Position 2



Crown (A) pulled two “clicks” out
Position 3



Thank you for choosing a timepiece from our Xezo for unite4:good collection. Your watch is fitted with Citizen Automatic movement, hacking feature, and [shock-absorber](#) device. The inner mechanism of the watch has a free swinging rotor that keeps the mainspring wound via the motion of your wrist. To achieve full power reserve of the automatic movement, please remember to wind the watch initially by rotating the winding crown 40 times. After wearing the watch for 36 hours, the movement will resume normal operation. A watch fitted with an automatic winding movement is rewound by the regular movements of your wrist.

Once fully wound, your watch will continue to keep time for approximately 42 hours after removing it from your wrist. Beyond this time, the watch will stop. You will then need to rewind it manually turning the crown (A) clockwise (approximately 40 turns) to provide it with the necessary power reserve. After that, your daily activity should wind the watch sufficiently to keep it running at night when it is not being worn. You should wear your watch everyday to ensure optimal rewinding.

Note: As this is a mechanical watch, quartz watch accuracy cannot be expected.

Setting the Time and Date

Setting the Time and Date

Important note: Do not change the date between 8 p.m. and 2 a.m. as the date may not change on the following day.

1.

Pull out the crown (A) to Position “2” (one “click” out). Rotate the crown (A) clockwise until the date shows one day earlier than the date you want to set.

Pull out the crown (A) to Position “3” (two “clicks” out). The seconds hand is stopped. Set the time by turning the crown (A) counter-clockwise to move the hour and minute hands forward. Turn the watch hands past 12 (at least once, or as many times as needed) to set the correct date.

2.

Once you have set the time or date, return the crown (A) to the pushed down Position “1” by pressing it against the case.

Remark:

You can synchronize the seconds hand with an official time signal (radio/ TV/Internet). When the crown (A) is pulled out in Position “3” (two “clicks” out), the seconds hand is stopped. As soon as the time setting has been synchronized, return the crown (A) to the pushed down position “1” by pressing it against the case.

Important Note: In order to insure that your watch remains water-resistant, it is important that crown (A) is always returned to the pushed down position “1”.

Specifications:

Case and Bracelet - 316L Stainless Steel (leather band is optional)

Glass - Swiss-made curved Sapphire Crystal with anti-reflection

Movement - Automatic by Citizen with shock-absorber, hacking feature

Case-back - Mineral Crystal Glass

Water-Resistance - 100M/330FT

Power reserve: ~42 hours, 28800 vibrations per hour

Servicing your Xezo Automatic watch

Although components in your watch have been manufactured from first-rate materials, certain parts are subject to natural wear and tear. It is vital that all moving parts are properly lubricated at all times and that the watch is cleaned at regular intervals to remove dirty oil.

We therefore, recommend that you have your watch serviced about once every 3-5 years.

Contact us for after-sales service.

<http://www.xezo.com>